

EXTERNAL TIMER HOOKUP:

A three or four pole plug is provided at the rear of the Canopy (For Commercial units only) for simple hook-up of external timers. Most timers on the market will attach easily. Simply unplug the three-pole timer plug, remove the cover, remove the wire jumper (Fig 8) and insert the two wires from the external timer back into the two outside terminals L1 and N. If you wish to by-pass timer on the bed, remove jumper wire (make sure to save jumper wire) and plug your two external timer wires into L1 and Ground (Fig. 9).




Fig. 8

Fig. 9